

A GUIDE TO YOUR **YOUTMESH** **TRI-BAND** **WI-FI 7 BOOSTER**

Customer edition



CONTENTS

- 4 Take a tour**
- 6 Set up the YouMesh Booster**
- 7 Log in to the YouMesh Booster**
- 8 Wi-Fi signal tips**
- 9 How to look after your YouMesh Booster**

TAKE A TOUR

Get to grips with all the lights and buttons and where things should be plugged in. It'll help you if you need to unplug and set it all up again, or to troubleshoot.

The lights, buttons and ports



The Tech Spec

YouMesh Booster with Wi-Fi 7

Tri-Band for more capacity:



Reaches further,
through walls




Faster, in a
small area




Even faster, less
interference

1x 1 Gb and 1x 2.5 Gb Ethernet LAN for fast hardwiring



SET UP THE YOUMESH BOOSTER



Plug it in and power it on.

The light will **flash white** while it's starting up.

It will **flash red** when it's ready to pair with your main Hub.



Move the YouMesh Booster close to the main Hub for pairing.

Press the **WPS button** on the **main Hub first**, hold for three seconds, and then press the **WPS button** on the **YouMesh Booster**.

Once pairing is opened the YouMesh Booster light will **flash blue**.



Only pair one YouMesh Booster with your main Hub at a time.

A **solid green light** will appear when the YouMesh Booster has paired.

When the light changes to **solid white**, unplug the YouMesh Booster from the power and move it where you need it most.

If the light is **solid amber** pairing has failed.

LOG IN TO THE YOUMESH BOOSTER

You can log in to your YouMesh Booster to check its connection.

1

Open a web browser,
enter the address:

http://192.168.1.1



2

Enter the default
username:

admin

3

Enter the GUI password
to log in (it's on the
bottom of the Hub)



WI-FI SIGNAL TIPS

To give your YouMesh Booster the best chance of Wi-Fi signal success.

Give your Hub space

An open, central location is your YouMesh Booster's happy place so the signal can reach around your home. Don't banish it behind the TV or shove it in a cupboard.

Don't put your Hub too high

Aim for a mid-level spot on a shelf for nice even Wi-Fi signal distribution. If it's perched high on a bookshelf it's like aiming your showerhead upwards.

Avoid signal stoppers

Thick walls and steel beams can block the Wi-Fi signal from your YouMesh Booster. If you've got an older house or a new extension, position your YouMesh Booster away from walls. And you can add another Booster for even more coverage.

Free up the frequency

Position your YouMesh Booster away from microwaves and cordless phones as they often use the same frequencies as Wi-Fi signals and can cause interference. Even the washing machine could affect it when it's on.

HOW TO LOOK AFTER THE YOUTHRESH BOOSTER

Here's some general YouMesh Booster self-care to keep it running at its best.

Keep it switched on

It's better for it and means it'll pick up our remote firmware updates.

Keep it cool and ventilated

Secure your network

Change your Wi-Fi password regularly.

Clean and dust it

If it gets clogged up, then it might overheat.

Restart it now and then

Who doesn't need a little reboot sometimes?

Manage your connected devices

Ditch anything you're not using regularly to free up bandwidth.

Need help?

Log in to **My Account** to get in touch with the team.

youfibre.com/myaccount

LET'S GO



youfibre.com/getstarted